



Guide for Configuring ARC Service on Hik-ProConnect

1. Installer can login Hik-ProConnect (using Installer account) to configure the ARC service. At first, you should add a site to manage device(s).




Then you can add device to the site.




Attention! ARC service is only supported by Hikvision encoding devices and AX Pro security control panels added by **Hik-Connect** Service.

Select an ARC company (your company) to provide services.



Enable ARC service for device(s). then authorize in Hik-Connect app.



Now you have finished the configurations in Hik-ProConnect.